



Step 1: Fold top flaps in, turn container upside down, and fold bottom flaps per instructions provided.



Step 2: Lock die cut bottom flaps leaving one bottom flap unsecured.



Step 3: Place container onto pallet and, using supplied Tri-Wall nails, nail each corner of the unsecured bottom flap to pallet as shown.



Step 4: Pull container upright onto the pallet.



Step 5: Insert the special poly liner bag and stretch around the container walls until firmly in place.



Step 6: Fill the container (bag) with the hazardous waste material.



Step 7: Twist the bag closed tightly to secure the hazardous material and seal the bag with an appropriate heavy-duty tape (2" pressure-sensitive poly tape or equivalent minimum) or twist tie.



Step 8: Carefully compress the bag of waste into the container and close the flaps.



Step 9: Seal the container permanently with 3" filament strapping tape.

Note: Personal protective equipment used will be contingent upon the site, safety and health plan at your company. Consult the safety supervisor at your company for instructions on handling hazardous waste.